

AS3020: Aerospace Structures Module 6: Introduction to Variational Mechanics

Instructor: Nidish Narayanaa Balaji

Dept. of Aerospace Engg., IIT-Madras, Chennai

October 28, 2024

Balaji, N. N. (AE, IITM)


AS3020*

October 28, 2024


Table of Contents

The Principle of Virtual Work

- The Elastic Solid
- Interpretation
- 2 Beam Bending: A Motivating Problem Setting
 - Calculus of Variations
 - Variational Derivation of Euler Bernoulli Beam Theory
 - Tutorial Example
- Bending of Axially Loaded Beams
 - Cables and Beams
 - Column Buckling



Very good book to read Lanczos [1]



Chapters 4, 5 in Megson [2]

AS3020*

1. The Principle of Virtual Work

• The idea behind the equilibrium principle is that the sum of all forces acting on a body is zero:

•

$$\int_{\Omega} forces = 0.$$

• In module 3, we used this in conjunction with the Cauchy Stress Principle to obtain general governing equations for an elastic solid:

$$\sigma_{ij,j} + f_i = 0$$
, on Ω , + $b.c.s$ on $\partial \Omega$.

- The work done by any force f_i on a system as it goes from $u_i^{(0)}$ to $u_i^{(0)} + \delta u_i$ is written as $f_i \delta u_i$.
- $\bullet\,$ The displacement field δu_i denotes a "virtual displacement", which is a mathematical idealization such that
 - it is small enough so as not to introduce changes in the force field;
 - it is compatible with any constraints that exist (B.C.s, for instance).

1. The Principle of Virtual Work

• The idea behind the equilibrium principle is that the sum of all forces acting on a body is zero:

$$\int_{\Omega} forces = 0.$$

• In module 3, we used this in conjunction with the Cauchy Stress Principle to obtain general governing equations for an elastic solid:

$$\sigma_{ij,j} + f_i = 0$$
, on Ω , + *b.c.s* on $\partial \Omega$.

- The work done by any force f_i on a system as it goes from $u_i^{(0)}$ to $u_i^{(0)} + \delta u_i$ is written as $f_i \delta u_i$.
- $\bullet\,$ The displacement field δu_i denotes a "virtual displacement", which is a mathematical idealization such that
 - it is small enough so as not to introduce changes in the force field;
 - it is compatible with any constraints that exist (B.C.s, for instance).

Under the stated assumptions, $\delta(\cdot)$ can be treated as a differential operator and we call it the **variational operator**.

1. The Principle of Virtual Work

• The work done by a virtual displacement field is termed as the *virtual work*. For a system under a certain force-field, the *virtual work* is a property of the system since so further deformation needs to be done.

Principle of Virtual Work

The virtual work of a system at equilibrium is zero.

- The *principle of virtual work* is merely a restatement of the principle of equilibrium, but it sometimes provides a more convenient analytical framework.
- Variational Mechanics is sometimes also referred to as analytical mechanics.

1.1. The Elastic Solid

The Principle of Virtual Work

• For the elastic solid, the principle of virtual work may be mathematically expressed as

$$\int_{\Omega} \underbrace{\sigma_{ij,j} \delta u_i}_{(\sigma_{ij} \delta u_i), j - \sigma_{ij} \delta u_{i,j}} + \int_{\Omega} f_i \delta u_i = 0.$$

• Applying Gauss divergence to the first term in the above we get,

$$\int_{\partial\Omega} \underbrace{\sigma_{ij}n_j}_{\text{surface traction } t_i} \delta u_i - \int_{\Omega} \sigma_{ij} \delta u_{i,j} + \int_{\Omega} f_i \delta u_i = 0.$$

• Due to stress tensor symmetry, the following equality holds:

$$\sigma_{ij}\delta u_{i,j} = \sigma_{ij}\delta\underbrace{\left(\frac{u_{i,j} + u_{j,i}}{2}\right)}_{E_{ij}} = \sigma_{ij}\delta E_{ij}.$$

• So the principle of virtual work reads,

$$\int_{\Omega} \sigma_{ij} \delta E_{ij} = \int_{\Omega} f_i \delta u_i + \int_{\partial \Omega} t_i \delta u_i$$

1.1. The Elastic Solid

The Principle of Virtual Work

Bala

• For the elastic solid, the principle of virtual work may be mathematically expressed as

$$\int_{\Omega} \underbrace{\sigma_{ij,j} \delta u_i}_{(\sigma_{ij} \delta u_i), j - \sigma_{ij} \delta u_{i,j}} + \int_{\Omega} f_i \delta u_i = 0.$$

• Applying Gauss divergence to the first term in the above we get,

$$\int_{\partial\Omega} \underbrace{\sigma_{ij}n_j}_{\text{surface traction } t_i} \delta u_i - \int_{\Omega} \sigma_{ij} \delta u_{i,j} + \int_{\Omega} f_i \delta u_i = 0.$$

• Due to stress tensor symmetry, the following equality holds:

$$\sigma_{ij}\delta u_{i,j} = \sigma_{ij}\delta\underbrace{\left(\frac{u_{i,j} + u_{j,i}}{2}\right)}_{E_{ij}} = \sigma_{ij}\delta E_{ij}.$$

• So the principle of virtual work reads,

$$\begin{array}{c} \text{``internal''}\\ \text{contributions} \end{array} \longrightarrow \int_{\Omega} \sigma_{ij} \delta E_{ij} = \int_{\Omega} f_i \delta u_i + \int_{\partial \Omega} t_i \delta u_i \xleftarrow{} \text{``external''}\\ \text{contributions} \end{array}$$

1.1. The Elastic Solid

The Principle of Virtual Work

• The formula above is valid in the general case but further simplifications are possible for the non-dissipative solid. Here we know that a strain energy density \mathcal{U} exists such that

$$\sigma_{ij} = \frac{\partial \mathcal{U}}{\partial E_{ij}}, \text{ and } \int_{\Omega} \mathcal{U} = \mathbf{U}.$$

• Substituting this for the internal components we get,

$$\int_{\Omega} \sigma_{ij} \delta E_{ij} = \int_{\Omega} \frac{\partial \mathcal{U}}{\partial E_{ij}} \delta E_{ij} = \int_{\Omega} \delta \mathcal{U} = \delta \mathbf{U}.$$

 \bullet Denoting the external contributions by Π such that

$$\delta \Pi = \int_{\Omega} f_i \delta u_i + \int_{\partial \Omega} t_i \delta u_i,$$

the principle of virtual work can be simply written as,

$$\delta(\mathbf{U} - \Pi) = 0.$$

• Note that while the strain energy U is fully described by the system, Π is loading-state dependent. Balaji, N. N. (AE, UTM) AS3020* October 28, 2024 6/18

1.2. Interpretation

The Principle of Virtual Work


- δ(U − Π) = 0 can be stated as For a system in equilibrium, the variation of total work done is zero.
- Intuitively, this means that the equilibrium deformation field of a system extremizes the quantity U-Π: Out of all possible deformation fields that satisfy the constraints, the system deforms in a way that extremizes the quantity U – Π.

Stability

• Suppose u^* is the equilibrium field, the "surplus energy" $U - \Pi$ in its neighborhood governs its stability.

AS3020*

- Consider the 1D example here with two extremal (equilibrium) points: u_1^* and u_2^* .
- The local behavior of the function U – Π governs the stability of the equilibria.



2. Beam Bending: A Motivating Problem Setting

• The kinematic and stress descriptions of a symmetric slender beam on the $(\underline{e}_1,\underline{e}_2)$ plane is:

$$u_1 = -X_2 v', \quad u_2 = v, \quad E_{11} = -X_2 E_y v'', \qquad \sigma_{11} = E_y E_{11}.$$

• The strain energy density in this case is

$$\mathcal{U} = \frac{E_y}{2} X_2^2 \left(v'' \right)^2.$$

 \bullet Integrating this over the section ${\mathcal S}$ we get the linear density

$$d\mathbf{U} = \frac{E_y I_{33}}{2} \left(v'' \right)^2.$$

• Considering transverse body force (per unit length) f and some point force F_P , the external energy is given as,

$$\Pi = \int_0^\ell f v + F_P v(X_P).$$

• Combining the two and integrating over the length we have,

$$U - \Pi = F_P v(X_P) + \int_0^\ell \frac{E_y I_{33}}{2} (v'')^2 - fv.$$

Balaji, N. N. (AE, IITM)

AS3020*

October 28, 2024

2.1. Calculus of Variations

Beam Bending: A Motivating Problem Setting

• Ignoring the $F_P v(X_P)$ term for the moment, the principle of virtual work is given as,

$$\delta(\mathbf{U} - \Pi) = \delta\left(\int_{0}^{\ell} \frac{E_{y}I_{33}}{2} (v'')^{2} - fv\right) = 0.$$

• This is a variational equation of the form,

$$\delta\left(\int_{\mathcal{D}}\mathcal{L}(v,v',v'',\dots)\right)=0$$

• Since δv are small quantities, we can apply Taylor's expansion on:

$$\int_{\mathcal{D}} \frac{\partial \mathcal{L}}{\partial v} \delta v + \frac{\partial \mathcal{L}}{\partial v'} \delta v' + \frac{\partial \mathcal{L}}{\partial v''} \delta v'' + \dots = 0.$$

• Applying integration by parts and observing that the variations $\delta v^{(n)}$ vanish at the boundaries, this simplifies as,

$$\int_{\mathcal{D}} \left(\frac{\partial \mathcal{L}}{\partial v} - \frac{d}{dx} \frac{\partial \mathcal{L}}{\partial v'} + \frac{d^2}{dx^2} \frac{\partial \mathcal{L}}{\partial v''} + \dots \right) \delta v = 0.$$

2.1. Calculus of Variations

Beam Bending: A Motivating Problem Setting

• Since the integral condition needs to be satisfied for all kinds of variations δu , the term within the parens must be zero:

$$\frac{\partial \mathcal{L}}{\partial v} - \frac{d}{dx} \frac{\partial \mathcal{L}}{\partial v'} + \frac{d^2}{dx^2} \frac{\partial \mathcal{L}}{\partial v''} + \dots = 0.$$

• This is known as *Euler-Lagrange Equations* and forms the basis of variational mechanics. It is the *functional analog* of function extremization.

Regular Calculus

- Find $x \in \mathbb{R}$ such that $f(x) : \mathbb{R} \to \mathbb{R}$ is **extremized**.
- First order optimiality condition: $\frac{df}{dx} = 0.$
- Second order optimality: $\frac{d^2f}{dx^2} :> 0(\min), < 0(\max).$

Calculus of Variations

- Find v(x) : ℝ → ℝ to extremize
 functional J = ∫ Ldx.
- First order optimality condition: $\frac{\partial \mathcal{L}}{\partial v} - \frac{d}{dx} \frac{\partial \mathcal{L}}{\partial v'} + \frac{d^2}{dx^2} \frac{\partial \mathcal{L}}{\partial v''} + \dots = 0.$
- Second order optimality: not so trivial.

2.2. Variational Derivation of Euler Bernoulli Beam Theory

Beam Bending: A Motivating Problem Setting

• Returning to the slender beam, we have as the Lagrangian,

$$\mathcal{L} = \frac{E_y I_{33}}{2} (v'')^2 - fv.$$

• Applying the Euler-Lagrange Equations we obtain,

$$\underbrace{-f}_{\frac{\partial \mathcal{L}}{\partial v}} + \frac{d^2}{dX_1^2} \underbrace{(E_y I_{33} v'')}_{\frac{\partial \mathcal{L}}{\partial v''}} = 0.$$

• For a beam with uniform properties $(E_y I_{33} \text{ constant along the beam})$, the governing equations may be written as

$$E_y I_{33} v'''' - f = 0 \,,$$

which is precisely what we expect from Euler-Bernoulli Beam Theory.

So far we've just reinvented the wheel and not really shown an example where the Variational approach really shines. We will do this next.

Balaji, N. N. (AE, IITM)

3. Tutorial Example

- Consider the following fixed-free beam along with a spring support at the end.
- The energy quantities are,

$$d\mathbf{U} = \frac{E_y I_{33}}{2} (v'')^2 + \frac{1}{2} k_T v_T^2, \qquad d\Pi = F_T v_T.$$

• Since the contributions from the load as well as the spring are from the boundaries, the bulk Equations of Motion (EoM) remains unchanged as: $E_i I_{33} v''' = 0.$

Boundary Conditions Clamped End $v = 0, v' = 0, X_1 = 0$ Loaded End $v = v_T, v'' = 0, X_1 = \ell$

• Solution in $X_1 \in (0, \ell)$ can be written in terms of v_T as:

$$v(X_1) = \frac{v_T}{2\ell^3} X_1^2 (3\ell - X_1).$$

Balaji, N. N. (AE, IITM)

3. Tutorial Example

• Substituting this back into the energy quantities and integrating it yields,

$$\mathbf{U} - \Pi = \underbrace{\frac{3E_y I_{33}}{2\ell^3} v_T^2}_{\int_0^\ell \frac{E_y I_{33}}{2} (v'')^2} + \frac{k_T}{2} v_T^2 - F_T v_T.$$

• Extremization of this quantity is trivial since everything just depends on a single unknown scalar, v_T . So we have,

$$\delta(\mathbf{U} - \mathbf{\Pi}) = \delta v_T \frac{\partial}{\partial v_T} (\mathbf{U} - \mathbf{\Pi}) = \delta v_T \left(\left(\frac{3E_y I_{33}}{\ell^3} + k_T \right) v_T - F_T \right).$$

• Setting this to zero for all δv_T implies

$$v_T^* = \frac{F_T}{k_T + \frac{3E_y I_{33}}{\ell^3}},$$

which is the equilibrium deflection.

• Plugging this back into the solution $v(X_1)$ above yields the full deformation shape.

Balaji, N. N. (AE, IITM)

4. Bending of Axially Loaded Beams

• We now draw upon the kinematic description from before for an axially loaded beam. The kinematics are,

$$u_1 = -X_2 v'(X_1), \quad u_2 = v(X_1).$$

• The corresponding axial strain is,

$$E_{11} = u_{1,1} + \frac{1}{2} \left(u_{1,1}^2 + u_{2,1}^2 \right)$$

= $-X_2 v'' + \frac{1}{2} \left(X_2^2 (v'')^2 + (v')^2 \right).$

• Considering a loading case that leads to a uniform axial stress (σ_{11}) of $\frac{P}{A}$, the strain energy can be written as

$$U = \int_{0}^{\ell} \left(\int_{\mathcal{S}} \frac{P}{A} E_{11} + \frac{E_y}{2} E_{11}^2 dA \right) dX_1$$

Retaining up
to $\mathcal{O}(v^2)$ terms
$$= \int_{0}^{\ell} \frac{E_y I_{33}}{2} \left(1 + \frac{P}{E_y A} \right) (v'')^2 + \frac{P}{2} (v')^2 dX_1$$

Balaji, N. N. (AE, IITM) AS3020* October 28, 2024 14/18

4. Bending of Axially Loaded Beams

• Considering transverse loads $f(X_1)$, the external work done is

$$\Pi = \int_{0}^{\ell} f v dX_1.$$

• The Lagrangian density is

$$\mathcal{L} = \mathbf{U} - \Pi = \frac{E_y I_{33}}{2} \left(1 + \frac{P}{E_y A} \right) (v'')^2 + \frac{P}{2} (v')^2 - fv.$$

• The Euler-Lagrange equations (for stationarity) are

$$E_y I_{33} \left(1 + \frac{P}{E_y A} \right) v'''' - P v'' - f = 0$$

• We expect the term $\frac{P}{E_yA}$ to be small in general.

4.1. Cables and Beams

Bending of Axially Loaded Beams

• The first simple case we will consider is the case of extremely small cross-sections. Here it can be said that

$$A \sim \mathcal{O}(\epsilon^2), \qquad I_{33} \sim \mathcal{O}(\epsilon^4).$$

 \bullet For sufficiently small $\epsilon,$ contributions from I_{33} can be negligible. In general, when

$$E_y I_{33} \ll P,$$

the following approximation may be made, wherein the equations governing transverse deflection become:

$$Pv'' + f = 0$$

• This governs the deflection of cables wherein the axial tension is the primary source of stiffness. This is also a second order differential equation, unlike beam bending, which is a fourth order equation.

4.2. Column Buckling

Bending of Axially Loaded Beams

• Another simplification is possible for the absence of transverse loads. Here the general equations read:

$$E_y I_{33} v'''' - \frac{P}{1 + \frac{P}{E_y A}} v'' = 0.$$

• Since $\frac{P}{E_{u}A} \ll 1$, we have

$$\frac{P}{1 + \frac{P}{E_y A}} = P - \frac{P^2}{E_y A} + \frac{P^3}{E_y A^2} - \dots = P,$$

which leads to

$$E_y I_{33} v'''' - P v'' = 0$$

• For compressive loading $(P \rightarrow -P)$, this is the classical buckling equation

$$E_y I_{33} v'''' + P v'' = 0$$

• Finding values of P where the trivial solution v = 0 is unstable leads to a Sturm-Liouville problem which will be treated in the **next module**.

Balaji, N. N. (AE, IITM)

AS3020*

References I

- C. Lanczos. The Variational Principles of Mechanics, Mathematical Expositions no. 4. Toronto: University of Toronto Press, 1949. ISBN: 978-1-4875-8177-0 978-1-4875-8305-7 (cit. on p. 2).
- T. H. G. Megson. Aircraft Structures for Engineering Students, Elsevier, 2013. ISBN: 978-0-08-096905-3 (cit. on p. 2).